

## Assembly and Safety Instructions - Please read before use

### PARTS - Please check that you have all the parts before proceeding

<b>(A)</b> Table Top x1	<b>(B)</b> Leg x4
<b>(C)</b> Lower Leg Brace x1	<b>(D)</b> Upper Leg Brace x1
<b>(E)</b> Bolt/Washer/Nut Set x9	<b>(F)</b> Center Cover x1
<b>(G)</b> Allen Key x2	<b>(H)</b> Spanner x2

### CARE AND MAINTENANCE

**NOTICE:** Do not use harsh or abrasive pads or cleaning solvents on this product.

#### Cleaning:

- Use a soft, damp cloth to clean the metal surfaces.
- A glass cleaner may be used to clean the glass surface of the Tabletop.
- Spot clean the Chairs as needed (using a soft cloth and a mild soap and water mixture). Allow them to dry before storing.

#### Storage:



- Remove the Umbrella from the Tabletop.
- To prevent mildew formation, make sure all parts are dry for storage.
- Store in a cool, clean, dry location out of foot traffic areas to avoid a tripping hazard.

#### Rust on Metal Finishes:

Rust is unavoidable when metal products are used outdoors. Rust is the chemical reaction between oxygen, water, and metal. To help avoid rust:

- Keep metal outdoor furniture out of bad weather as much as possible.
- Avoid knocking metal parts against each other or dragging items across a concrete or tile floor. Each damaged area in the metal is a place for oxygen and water to contact the metal and begin rust formation.
- Every three to four weeks, and before storing, wash metal parts with soapy water, using a soft brush in the crevices. Rinse thoroughly, dry completely, and then coat the metal with a car wax of your choice. This temporarily protects the metal from the oxygen and water in the air. Since the coating is thin, however, it must be replenished periodically to retain its protective qualities.

### ASSEMBLY



#### TABLE


1. Position the Tabletop (A) upside down on a soft, flat surface.
2. Insert the Legs (B) into the corresponding holes on the inside of the Tabletop (A) (see Fig. 1).  
**NOTE:** Use a rubber mallet to gently tap the Legs in if necessary.
3. Lower the Upper Leg Brace (D) between the Legs (B) and align it with the corresponding holes on the inside of the Legs (B) (see Fig. 2). Insert a Bolt from a Bolt/Washer/Nut Set (E) through a washer, then the outside of the Leg (B) and attach a Washer and a Nut (see Fig. 2). Partially tighten the Nut onto the Bolt. Repeat to attach the remaining Legs (B) to the Upper Leg Brace (D).  
**NOTE:** Premature tightening of any one Bolt may cause misalignment of the remaining Bolt holes.
4. Repeat step 3 to attach the Lower Leg Brace (C) (see Fig. 2).
5. Tighten all Bolts using the Allen Key (G) and the Wrench (H), and then place a Bolt End Cover (E) and Bolt Top Cover (E) on the end and top of the Bolts (see Fig. 2).
6. Position the assembled Table right side up.

**CAUTION:** Always place the Table on a flat, level, stable surface. Fig. 3

#### UMBRELLA

This unit includes an Umbrella. Remove the Center Cover (F) (see Fig. 3). Insert the pole of the Umbrella through the center of the Table, the center of the Lower Leg Brace (C), and down to the ground (see Fig. 3).


When finished using the Umbrella, remove it and replace the Center Cover (F). **CAUTION:** Always use an Umbrella Base (not included) to support the Umbrella when using the Umbrella with the Table. The absence of an Umbrella Base may result in Table instability and/or overturning.



#### CHAIRS

This unit includes six pre-assembled Folding Chairs. Unfold and place the Chairs around the Table and on a flat, level, stable surface.

### ASSEMBLY RATING



**1**  
SIMPLE

### WARNING



**PINCH POINT HAZARD**  
Keep fingers clear of hinges  
when folding and unfolding  
ONLY ADULTS SHOULD SET UP  
AND TAKE DOWN THIS PRODUCT

\*FOR OUTDOOR USE ONLY

### WARNING - To reduce the risk of serious personal injury:

- This product includes small parts (e.g., screws, washers). To avoid possible choking hazards, use extreme caution when assembling this product near children under three years of age and pets.
- Chairs are pre-assembled. Use caution when unfolding/folding a Chair to avoid fingers or other body parts becoming entrapped between parts of the Chair.
- Keep small parts out of the reach of children under three years of age and pets.

### CAUTION - To reduce the risk of personal injury:

- This product is intended solely for non-commercial, non-industrial, outdoor use in the support of persons and objects within the load capacities mentioned below, and to provide shade from the sun. Do not use this product for any other purpose than intended.
- Do not place more than 102 kg on a Chair and no more than 30 kg on the Patio Table. Exceeding these weight limits may cause the product to collapse, crack, or break resulting in personal injury.
- Adult supervision is necessary when a child is using this product. Never leave a child unattended while they are using this product.
- Do not stand or sit on the Patio Table; do not stand on the Chairs. Do not use the Patio Table or the Chairs as a stepladder.
- Although the Umbrella provides shade, users of this product should still wear protection against the burning effects of sunlight on their skin.
- Keep the product away from open flames and other heat sources.
- Always place the product on a flat, level, stable surface.
- Inspect the product monthly. Make sure all parts are secure, retightening any Screw or Bolt if necessary. If any part of the product is damaged in a way that could jeopardize the safety of a user, or if any part shows a sign of instability, permanently discontinue use of the product.

### NOTICE - To reduce the risk of product and/or property damage:

- Ensure all parts of the product are securely attached before each use.
- Inspect the product monthly. Make sure all parts are secure, retightening any Screw or Bolt if necessary. If any part of the product is damaged in a way that could jeopardize the safety of a user, or if any part shows a sign of instability, permanently discontinue use of the product.
- The product's umbrella is not for use during inclement weather. Remove the Umbrella from the unit and store it before the arrival of inclement weather.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE