



Please take time to familiarise yourself with the product prior to assembly. It is important to read all of these instructions and safety tips carefully before using the product. To avoid any accidents or damage to the product, please follow all assembly instructions, only use the product as instructed and only for its intended use. Retain these instructions for future reference and if you are passing this product to a third party, always make sure this documentation is included.

## **Safety Notes:**

This product is for outdoor use only in domestic setting. This product is not designed for commercial use.

Do not climb or jump on this product. This is not a toy or climbing frame for children.

Do not assemble in strong winds.

When setting up, make sure it is stable and that it is inserted to a sufficient depth.

This product requires two people for assembly.

## **Product Parts:**

Remove the product from the box and check all the parts listed below are included before proceeding with the assembly. Remove all the packaging from the product and place it in the box or dispose of safely.



## Installation:

We recommend assembly on a flat surface in horizontal position before turning to vertical postion and setting up at the final location. Assembly of this product requires two persons. Start assembling this product from the bottom to the top dividing this arch into two sections (marked with dotted line on the drawing). Connect top sections together once you have assembled both halves completely. To ensure a secure footing of the garden arch simply stick it into the ground or, for the best support, embed it in concrete in the soil. A depth of approx. 15cm is recommended.

## Care and maintenance:

Clean this arch when required with mild detergent and soft cloth.

Regularly check to ensure that all fittings and fixings are securely fastened. If loose please tighten, as necessary. A thin coating of spray on car wax may be applied to the metal surfaces to help prevent rusting.





